



# TROY

## REAR FOLDING BATTLESIGHT



**WARNING! Observe safe firearm handling practices at all times. Make sure the firearm is unloaded and safety is engaged before starting installation. Installation should be performed by a professional gunsmith.**



1. Unscrew clamp assembly and place sight so as to allow clamp screw to rest in foremost rail cross-slot of flat top receiver.



2. Apply one drop of thread locking compound to expose threads. Replace clamp and tighten screw while pushing sight forward against cross-slot.



Adjustments: Can be made with a 5.56mm bullet tip (left) or a coin using the coin slot (right). To move bullet impact right, turn adjustment wheel to the right/clockwise. To move bullet impact left, turn adjustment wheel to the left/counter clockwise.

Operation: To raise sight, grasp and pull up until sight locks in the upright position. To fold sight, depress button on the left side of the base and fold down.

### Zeroing Procedures

1. Fire a group of four (4) shots and measure average distance from point of aim to point of impact.
2. Adjust front sight for elevation only.
3. Windage adjustments are made with rear sight.
4. Confirm zero with a group of four aimed shots and adjust if necessary

TMIM\_RearFoldSight\_9-21-12

WWW.TROYIND.COM • West Springfield, Massachusetts 01089 U.S.A. • Tel: (866) 788-6412 • Fax: (413) 383-0339 • email: sales@troyind.com



# TROY

## REAR FOLDING BATTLESIGHT



**WARNING! Observe safe firearm handling practices at all times. Make sure the firearm is unloaded and safety is engaged before starting installation. Installation should be performed by a professional gunsmith.**



1. Unscrew clamp assembly and place sight so as to allow clamp screw to rest in foremost rail cross-slot of flat top receiver.



2. Apply one drop of thread locking compound to expose threads. Replace clamp and tighten screw while pushing sight forward against cross-slot.



Adjustments: Can be made with a 5.56mm bullet tip (left) or a coin using the coin slot (right). To move bullet impact right, turn adjustment wheel to the right/clockwise. To move bullet impact left, turn adjustment wheel to the left/counter clockwise.

Operation: To raise sight, grasp and pull up until sight locks in the upright position. To fold sight, depress button on the left side of the base and fold down.

### Zeroing Procedures

1. Fire a group of four (4) shots and measure average distance from point of aim to point of impact.
2. Adjust front sight for elevation only.
3. Windage adjustments are made with rear sight.
4. Confirm zero with a group of four aimed shots and adjust if necessary

TMIM\_RearFoldSight\_9-21-12

WWW.TROYIND.COM • West Springfield, Massachusetts 01089 U.S.A. • Tel: (866) 788-6412 • Fax: (413) 383-0339 • email: sales@troyind.com