



WARNING! Observe safe firearm handling practices at all times. Make sure the firearm is unloaded and safety is engaged before starting installation. Installation should be performed by qualified gunsmith only!



1. Parts needed: TRX Low Profile Q.D. Swivel Mount, rear clamp, screw, and hex wrench.



2. Put small drop of thread locking compound on screw threads. Insert screw and hex wrench into adapter.



3. Place adapter retainer on index finger with nubs face up.



4. Place retainer under hole where you want adapter to be.



5. Place adapter into hole over retainer and tighten screw.



6. When completed the TRX Low Profile Q.D. Swivel Mount should resemble what is shown above.