



WARNING! Observe safe firearm handling practices at all times. Make sure the firearm is unloaded and safety is engaged before starting installation.



1. Pass sling strap through attachment device (swivel, mash hook, socket).



2. Pass strap through both plastic buckles.



3. Feed the end of the strap back over the top of the first buckle and through the second.



4. Pull strap to tighten front sling connection.



5. Remove excess strap from padded area of sling and pull through buckle. Pass strap through sling attachment (Q. D. Swivel, etc.) and weave strap through both sides of buckle.



6. Pull strap to tighten.



7. Adjust buckle to preferred length. Pull end of strap to tighten.



8. Insert excess strap into padded section of sling.



9. Attach bungeed end of sling to front of rifle and opposite end of sling to the rear of the rifle at each attachment point.